

Lumascape Lighting Industries Pty Ltd 38-44 Enterprise Street, Cleveland, QLD 4163, Australia

07 3286 2299 07 3286 6599

sales@lumascape.com.au W www.lumascape.com.au

PO Box 1875, Cleveland D.C., QLD 4163, Australia

SPOTLIGHT & FLOODLIGHT



MODEL LS421LED

INSTALLATION TYPE Spot & Floodlight

IP RATING IP66 / IP67

SUPPLY VOLTAGE 24 V DC INSTRUCTIONS COVER Single Colour

INSTALLATION INSTRUCTIONS

Single Colour Dimming

(±90°C (€ C N653

RGB











KEEP AWAY FROM DO NOT USE SILICONE KEEP ELECTRONICS FREE FLAMMABLE MATERIAL ON OUTSIDE SURFACE FROM DIRT AND MOISTURE




DO NOT HOSE OF

LS421LED Centria

Warranty void if not installed as per installation instructions


the mounting surface.






Failure to isolate power supply before installation or maintenance may result in fire, serious injury, electric shock, death and may damage the luminaire.







Wiring Diagrams & Dip Switch Settings (Applicable to RGB & Single Colour Dimming with 24 V DC only)

SWITCH SETTINGS RJ45 DMX WIRING X100 X10 Wire# Wire Colour **DMX512 Function** X1 **Function** 0 0 0 RDM address 1 white/green data 1+ 2 DMX address/RDM capable green data 1-0 0 1 but no writes (responds to 3 white/orange Not Assigned rotary address) 4 blue Not Assigned 5 1 0 Last address white/blue Not Assigned 5 9 9 0 O output no DMX response 6 orange Not Assigned 9 9 1 Ch1 100% 7 white/brown **GND** 9 9 2 Ch2 100% 8 Not Assigned brown 9 9 3 Ch3 100% Drain 9 9 4 Ch1,2,3 0% 9 9 5 Ch1,2,3 100% 9 6 Ch1,2 100% 9 9 7 Ch2,3 100% 9 8 Ch1,3 100% 9 9 9 9 rainbow 0000000 CH₃ DMX IN **DMX OUT** CH₁ CH₂ X100 X10 201

SAFETY INSTRUCTIONS

WARNING - To reduce the risk of FIRE or INJURY:

- 1. Luminaires and transformers to be installed by licensed electrical contractors.
- Luminaires to be used for intended purpose only.
- 3. Do not operate the luminaires with a missing or damaged parts.
- 4. Use only genuine Lumascape parts to replace damaged or missing components.
- 5. Refer to instructions for installation and operating requirements.
- 6. Ensure installation complies with local regulations

Voltage insulation test (megger) will permanently damage product and will void warranty.

SAVE THESE INSTRUCTIONS.